

CPU Carrier



Insert (2) 1/4" X 3" screws with (2) washers under their heads into leg holes as shown.

Wax screws prior to insertion.



Slide Stub Rails onto screws.

Make sure washers are under the heads of the screws, not between the Stub Rail and Leg.

Tighten screws



Drop Carrier Board onto Stub Rails.

Carrier Board may be either 1pc as shown, or be made up of 2 or 3 separate boards.

Newer Stub Rails may not have the bosses on their ends as shown

For outside mount of CPU Carrier go to <http://www.hardwoodfurniture.com/carrier-outside.htm>