

## Tilt Adjustment



Wax the (6) B1 Stationary Slides on their inner surfaces. Remove labels if still attached.

Slide Small Work Surface Assembly onto lower pair of B1 Stationary Slides.

Install (2) F4 Tilt Pins as shown

Repeat procedure for Large Work Surface Assembly.



For more information on using the F4 Tilt Pins, go to Page 8 of this Assembly

When finished your desk should look like this.

Stop Rods are used to keep items from sliding off tilted Work Boards. To install, insert one end of Stop Bar into hole in Board Side. Bend Stop Rod as shown to install other end of Stop Rod in corresponding hole in opposite Board Side

